



Component List

(Senarai Komponen)

Tilting Pan




TP3237

Made in Malaysia

Thank you for purchasing BERJAYA product. Please read this service manual carefully before operating the product.
Please keep this manual in a safe place for future reference.

EXPLOSIVE DRAWING



COMPONENT LIST

No	Description		BOM Code
1	Copper Nozzle + Bush		C-GG2A + PI-B1/4 x 1/2
2	Piezo Ignitor		GE-PIEZO
3	High Tension Cable - 600mm		GE-WL600
4	Electrode Square M4		GE-ES
5	Gas Valve		VA7988-B7
6	Burner Nozzle		C-BJS52
7	Burner	Old	BR-H23
		New	BR-SH-1
8	Pilot Burner		GE-LPG332-PB
			GE-NG334-PB
9	Thermocouple - 600mm		GE-L600TC
10	Completed Gear Set		MC-TP3237
11	Copper Fitting		C-TPCF
12	Knob		KN-FLAT

MEMO

Please fill in the following at the purchasing time for future service reference.

Model Number :	
Purchasing Date :	
Dealer's Name :	
Address :	
Contact Number :	Home : Handphone :
Comment :	

The manufacturer reserves the right to change in design, equipment and technical features at any time. Accordingly, no claims based on data, illustration or descriptions in this operation manual will be admitted. English version is to be referred for any ambiguity

This operation manual is for usage guideline. The technical data details and usage instructions are given with our best knowledge of product and with good faith. It should not bind the sales agent or manufacturer to attendance in court or to appear in any enquiry before any government or statutory bodies.